

**step1** → **step2** → **step3** → **step4** →

a x 6  
b x 2  
a x 2  
e x 4  
d x 1  
c x 2  
f x 3

**Fittings**

a		b		c		d	
e		f		g		h	
	4pcs		3pcs		5# 1pcs		4# 1pcs

**1** **2** **3** **4**

**1. Lumbar adjustment:**  
The pads is designed to be flexible, allowing it to move with the user by 40mm, provide comfortable ergonomic support for abroad range of users:

**2. Armrest height adjustment :**  
The armrests height can be adjusted according to different body sizes:

**3. Tilt tension adjustment :**  
Turn the knob to clockwise direct to tight the tilt tension. Turn the knob to anticlockwise direct to loose the tilt tension.

**4. Adjustable seat height and locking:**  
Pull or push the control lever to adjust the seat to a comfortable height.  
Pulled out the handle, the tilting of chair can be adjusted freely, locked when take back.